
ASSEMBLY INSTRUCTIONS PRINTED LED HOUSING | TARGET BLU EYE 2



1. Fold both legs of the microswitches into the recesses and cut about one third of the length of the contacts.



- 2. Place the microswitches in the housing with the contacts facing inwards. Place the housing on a cardboard plate in such a way that the microswitches are clear of the surface and are not pressed inward.
- 3. Using a toothpick, apply a quick-drying glue (superglue) to the location of the red arrows.
- 4. Insert the plug of the microswitches into the "switch" connector of the LED display.
- 5. Place the LED display in the housing and glue it with hot melt at the locations indicated by the 5 green arrows.
- 6. Cut the wires for the microswitches to length.

NB! Red/black is connected to microswitch 1. Green/white to microswitch 2. This order is important!

7. Strip the wires and tin them as well as the contacts of the microswitches.



ASSEMBLY INSTRUCTIONS PRINTED LED HOUSING | TARGET BLU EYE 2

- 8. Solder the wires to the contacts of the microswitches.
- 9. Carefully remove the heat shrink tubing from the display cable.
- 10. Insert the plug of the display cable into the bus connector of the display.
- 11. Apply hot melt to the location of the green arrow and fold the display cable up through the recess in the housing.



- 12. Apply a quick-drying sealant or 2-component adhesive to the bottom plate of the housing.
- 13. Press the two parts of the housing together and, depending on the sealant or glue used, keep the two parts pressed together with a clamp until maximum adhesion is achieved.

